SIEMENS

For replacement parts information or an application guide, visit our website at www.usa.siemens.com/controls, or contact your local Siemens sales office.

Replacement Parts

E87010-A0093-T010-A4-87JC

March, 2016

Pump Panel Size 3, 3½



AWARNING


Hazardous voltage
Can cause death or serious injury.

Disconnect power and control voltages before installation or maintenance on this equipment.


IMPORTANT

THESE INSTRUCTIONS DO NOT PURPORT TO COVER ALL DETAILS OR VARIATIONS IN EQUIPMENT, NOR TO PROVIDE FOR EVERY POSSIBLE CONTINGENCY TO BE MET IN CONNECTION WITH INSTALLATION, OPERATION OR MAINTENANCE. SHOULD FURTHER INFORMATION BE DESIRED OR SHOULD PARTICULAR PROBLEMS ARISE WHICH ARE NOT COVERED SUFFICIENTLY FOR THE PURCHASER'S PURPOSES, THE MATTER SHOULD BE REFERRED TO THE LOCAL SIEMENS SALES OFFICE.

THE CONTENTS OF THIS INSTRUCTION MANUAL SHALL NOT BECOME PART OF OR MODIFY ANY PRIOR OR EXISTING AGREEMENT, COMMITMENT OR RELATIONSHIP. THE SALES CONTRACT CONTAINS THE ENTIRE OBLIGATION OF SIEMENS. THE WARRANTY CONTAINED IN THE CONTRACT BETWEEN PARTIES IS THE SOLE WARRANTY OF SIEMENS. ANY STATEMENTS CONTAINED HEREIN DO NOT CREATE NEW WARRANTIES OR MODIFY THE EXISTING WARRANTY.



Item	Part Name			Part Number
В	Switch Block Assembly	250V / 600V	100A 200A	HFB63 MCS620R
С	Load Base Assembly (Base, Clips, Lugs, Hardware)	250V / 600V	100A	HBB63
		250V / 600V	200A	FCK620
E	Motor Circuit Protector	600 VAC	100A 125A	ED63A100 ED63A125
F	Handle Only	for Disconnect for Disconnect	100A 200A	75D73944015 75D73944023
	Complete Handle Assembly Yoke Lever (Not Shown)	for Circuit Breaker for Disconnect for Disconnect for Circuit Breaker	100A 200A	75D73944025 75D68257103 75D68257068 75D68257080
G H K	H-O-A Selector Switch Start Push Button Reset Assembly			52SA2CBA1 52PA8A1K 49MBRS



Item	Part Name			Part Number
			Motor FLA	1
Α	Starterwith ESP200	Size 3 Size 3½	25-100A 50-200A	14HUG32A* 14IUH32A*
	Starter with Ambient Compensated Bimetal Overload Relay	Size 3 Size 3½		14HP32A*81 14IP32A*81
A_1	Contacts & Spring, One Complete Pole	Size 3 Size 3½		75HF14 75IF14
A_2	Auxiliary Contact			49AB10
A ₃	Coil 60 Hz	50 Hz		
	110-120 / 220-240V 220-240/ 440-480V 200-208V	110 / 190-220V 190-220/ 380-440V		75D73251A 75D73251C 75D73251D
	550-600V	550V		75D73251E
A_4	ESP200 Overload Relay Only	Size 3 Size 3½	25-100A 50-200A	48BTG3S00 (3UB81334GW2) 48BTH3S00 (3UB81334HW2)
	Ambient Compensated Bimetal Overload Relay	Size 3 & 3½		48HC38AA3

 $Note: When \ ordering \ replacement \ parts, \ give \ catalog \ number \ of \ control \ and \ part \ name \ and \ number. \ Replace \ the \ (*) \ with \ letter \ from \ the \ coil \ table.$

etter
Α
С
D
Е