

### RTE Series — Analog Timers

#### Key features of the RTE series include:

- 20 time ranges and 10 timing functions
- Time delays up to 600 hours
- Space-saving package
- High repeat accuracy of ± 0.2%
- ON and timing OUT LED indicators
- Standard 8- or 11-pin and 11-blade termination
- 2 form C delayed output contacts
- 10A Contact Rating



Cert. No. E9950913332316 (EMC, RTE) Cert. No. BL960813332355 (LVD, RTE)







#### **Contact Ratings**

oomao	t matingo	
Contact	Configuration	2 Form C, DPDT (Delay output)
	ble Voltage / ble Current	240V AC, 30V DC / 10A
	ım Permissible ng Frequency	1800 cycles per hour
	Resistive	10A 240V AC, 30V DC
Rated	Inductive	7A 240V AC, 30V DC
Load	Horse Power Rating	1/6 HP 120V AC, 1/3 HP 240V AC
126.	Electrical	500,000 op. minimum (Resistive)
Life	Mechanical	50,000,000 op. minimum

#### **General Specifications**

General Specificat	ions								
Operation System			Solid state CMOS C						
Operation Type			Multi-Mode						
Time Range			0.1sec to 600 hours	3					
Pollution Degree			2 (IE60664-1)						
Over voltage category			III (IE60664-1)						
		AF20	100-240V AC(50/60	)Hz)					
Rated Operational Vol	tage	AD24	24V AC(50/60Hz)/24	4V DC					
		D12	12V DC						
		AF20	85-264V AC(50/60H	łz)					
Voltage Tolerance		AD24	20.4-26.4V AC(50/6	60Hz)/21.6-26.4V DC					
		D12	10.8-13.2V DC						
Input off Voltage			Rated Voltage x10%	6 minimum					
<b>Ambient Operating Te</b>	mperatur	е	-20 to +65°C (witho	ut freezing)					
Ambient Storage and	Transport	Temperature	-30 to +75°C (witho	ut freezing)					
Relative Humidity	-	-	35 to 85%RH (with	out condensation)					
Atmospheric Pressure	•		80kPa to 110kPa (Operating), 70kPa to 110kPa (Transport)						
Reset Time			100msec maximum						
Repeat Error			±0.2%, ±20msec*						
Voltage Error			±0.2%, ±20msec*						
Temperature Error			±0.5%, ±20msec*						
Setting Error			±10% maximum						
Insulation Resistance			100M $\Omega$ minimum (500V DC)						
			Between power and	000V AC, 1 minute					
Dielectric Strength			Between contacts of	of different poles: 200	00V AC, 1 minute				
			Between contacts of	of the same pole:1000	OV AC, 1 minute				
<b>Vibration Resistance</b>			10 to 55Hz amplitud	de 0.5mm² hours in e	ach of 3 axes				
			Operating extremes	s: 98m/sec² (10G)					
Shock Resistance			Damage limits: 490	lm/sec <sup>2</sup> (50G)					
			3 times in each of 3	3 axes					
<b>Degree of Protection</b>			IP40 (enclosure) (IE	C60529)					
	TYPE		RTE-P1, -B1		RTE-P2, -B2				
Davies Canaumatica	AF20	120V AC/60Hz	6.5VA		6.6VA				
Power Consumption (Approx.)	AIZU	240V AC/60Hz	11.6VA		11.6VA				
(	24V AC	60Hz/DC	3.4VA/1.7W		3.5VA/1.7W				
	D12		1.6W 1.6W						
Mounting Position			Free						
Dimensions		RTE-P1, P2	40Hx 36W x 77.9D mm						
Dimensions		RTE-B1, B2	40Hx 36W x 74.9D mm						
Weight (Approx.)			RTE-P1	RTE-P2	RTE-B1, -B2				
aut (, thb.ov.)			87g	89g	85g				



www.idec.com


\*For the value of the error against a preset time, whichever the largest. applies.

798

**RTE Series** 

### **Part Numbering Guide**

RTE series part numbers are composed of 4 part number codes. When ordering a RTE series part, select one code from each category. Example: **RTE-P1AF20** 



#### **Part Numbers: RTE Series**

	Description	Part Number Code	Remarks
① Series	RTE series	RTE	For internal circuits, see next page.
② Terminal Style	Pin	Р	Salast and only
© Terrifinal Style	Blade	В	Select one only.
	ON-delay, interval, cycle OFF, cycle ON	1	Each function group has different timing functions.
3 Function Group	ON-delay, cycle OFF, cycle ON, signal ON/OFF delay, OFF-delay, one-shot	2	See page 794.
	100 to 240V AC(50/60Hz)	AF20	
④ Input Voltage	24V AC(50/60Hz)/24V DC	AD24	
	12V DC	D12	

#### **Part Numbers**

Voltage	Power T	riggered	Start Input	Triggered
voitage	8-Pin	Blade	11-Pin	Blade
12V DC	RTE-P1D12	RTE-B1D12	RTE-P2D12	RTE-B2D12
24V AC/DC	RTE-P1AD24	RTE-B1AD24	RTE-P2AD24	RTE-B2AD24
100-240V AC	100-240V AC RTE-P1AF20 F		RTE-P2AF20	RTE-B2AF20


#### Time Range Determined by Time Range Selector and Dial Selector

	Dial	0 - 1	0 - 3	0 - 10	0 - 30	0 - 60
	Second	0.1 sec - 1 sec	0.1 sec - 3 sec	0.2 sec - 10 sec	0.6 sec - 30 sec	1.2 sec - 60 sec
ige	Minute	1.2 sec - 1 min	3.6 sec - 3 min	12 sec - 10 min	36 sec - 30 min	1.2 min - 60 min
Ran	Hour	1.2 min - 1 hr	3.6 min - 3 hr	12 min - 10 hr	36 min - 30 hr	1.2 hr - 60 hr
	10 Hours	12 min - 10 hr	36 min - 30 hr	2 hr - 100 hr	6 hr - 300 hr	12 hr - 600 hr



#### **Timing Diagrams**

#### RTE-P1, -B1





1. RTE-B1: Do not apply voltage to terminals #2, #5 & #8.

 IDEC sockets are as follows: RTE-P1: SR2P-06\* pin type socket, RTE-B1: SR3B-05\* blade type socket, (\*-may be followed by suffix letter A,B,C or U).

#### A: ON-Delay 1 (power start)

Set timer for desired delay, apply power to coil. Contacts transfer after preset time has elapsed, and remain in transferred position until timer is reset. Reset occurs with removal of power.

Item	Terminal Nu	nber	Operat	ion	
Power	(1) 2 - 7 (2) A - B				
Delayed	(1) 1 - 4, 5 - 8 (2) 1 - 7, 3 - 9	(NC)			
Contact	(1) 1 - 3, 6 - 8 (2) 4 - 7, 6 - 9	(NO)			
Indicator	PWR				
indicator	OUT				
Set Time			T		

#### C: Cycle 1 (power start, OFF first)

Set timer for desired delay, apply power to coil. First transfer of contacts occurs after preset delay has elapsed, after the next elapse of preset delay contacts return to original position. The timer now cycles between on and off as long as power is applied (duty ratio 1:1).

Item	Terminal Nur	nber			Op	eration		
Power	(1) 2 - 7 (2) A - B							
Delayed	(1) 1 - 4, 5 - 8 (2) 1 - 7, 3 - 9	(NC)						
Contact	(1) 1 - 3, 6 - 8 (2) 4 - 7, 6 - 9	(NO)						
Indicator	PWR							
mulcator	OUT							
Set Time			<b>←</b>	<b>←</b>				

#### B: Interval (power start)

Set timer for desired delay, apply power to coil. Contacts transfer immediately, and return to original position after preset time has elapsed. Reset occurs with removal of power.


				'	
Item	Terminal Nu	nber	Opera	tion	
Power	(1) 2 - 7 (2) A - B				
Delayed	(1) 1 - 4, 5 - 8 (2) 1 - 7, 3 - 9	(NC)			
Contact	(1) 1 - 3, 6 - 8 (2) 4 - 7, 6 - 9	(NO)			
Indicator	PWR				
indicator	OUT				
Set Time			T	-	

#### C: Cycle 3 (power start, ON first)

Functions in same manner as Mode C, with the exception that first transfer of contacts occurs as soon as power is applies. The ratio is 1:1. Time 0n = Time Off

Item	Terminal Nu	nber				Op	eration			
Power	(1) 2 - 7 (2) A - B									
Delayed	(1) 1 - 4, 5 - 8 (2) 1 - 7, 3 - 9	(NC)							П	
Contact	(1) 1 - 3, 6 - 8 (2) 4 - 7, 6 - 9	(NO)								
Indicator	PWR									
muicator	OUT									
Set Time			4	_	<b>←</b>					

## Timing Diagrams con't RTE-P2, -B2



- 1. RTE-P2: Do not apply voltage to terminals #5, #6 & #7.
- 2. RTE-B2: Do not apply voltage to terminals #2, #5 & #8.
- IDEC sockets are as follows: RTE-P2: SR3P-05\* pin type socket, RTE-B2: SR3B-05\* blade type socket, (\*-may be followed by suffix letter A,B,C or U).

#### A: ON-Delay 2 (signal start)

When a preset time has elapsed after the start input turned on while power is on, the NO output contact goes on.

Item	Terminal Nur	nber	Operat	ion	
Power	(A) 2 - 10 (B) A - B				
Start	(A) 5 - 6 (B) 2 - 5				
Delayed	(A) 1 - 4, 8 - 11 (B) 1 - 7, 3 - 9	(NC)			
Contact	(A) 1 - 3, 9 - 11 (B) 4 - 7, 6 - 9	(NO)			
Indicator	PWR				
IIIUICatui	OUT				
Set Time			T T		

#### C: Cycle 4 (signal start, ON first)

When the start input turns on while power is on, the NO contact goes on. The output oscillates at a preset cycle (duty ratio 1:1).

Item	Terminal Nur	nber				Operat	ion					
Power	(A) 2 - 10 (B) A - B											
Start	(A) 5 - 6 (B) 2 - 5											
Delayed	(A) 1 - 4, 8 - 11 (B) 1 - 7, 3 - 9	(NC)										
Contact	(A) 1 - 3, 9 - 11 (B) 4 - 7, 6 - 9	(NO)										
Indicator	PWR											
iliulcatui	OUT											
Set Time			<b>←</b>	T	<b>←</b>	<b>←</b>	T	<b>←</b>	T	T	<del>∢→</del> Ta	

#### E: Signal OFF-Delay

When power is turned on while the start input is on, the NO output contact goes on. When a preset time has elapsed after the start input turned off, the NO output contact goes off.

Item	Terminal Nu	nber	Г			Op	eration				
Power	(A) 2 - 10 (B) A - B										
Start	(A) 5 - 6 (B) 2 - 5										
Delayed	(A) 1 - 4, 8 - 11 (B) 1 - 7, 3 - 9	(NC)				Г					
Contact	(A) 1 - 3, 9 - 11 (B) 4 - 7, 6 - 9	(NO)									
Indicator	PWR										
indicator	OUT										
Set Time					-		<del>≺ →</del> Ta	<b>←</b>	-	<del>≺ →</del> Ta	

#### B: Cycle 2 (signal start, OFF first)

When the start input turns on while power is on, the output oscillates at a preset cycle (duty ratio 1:1), starting while the NO contact off.

Item	Terminal Number Operation													
Power	(A) 2 - 10 (B) A - B													
Start	(A) 5 - 6 (B) 2 - 5													
Delayed Contact	(A) 1 - 4, 8 - 11 (B) 1 - 7, 3 - 9	(NC)												
	(A) 1 - 3, 9 - 11 (B) 4 - 7, 6 - 9	(NO)												
Indicator	PWR													
	OUT													
Set Time				<b>←</b>	T	<b>←</b>	<del>∢⊁</del> Ta							

#### D: Signal ON/OFF-Delay


When the start input turns on while power is on, the NO output contact goes on. When a preset time has elapsed while the start input remains on, the output contact goes off. When the start input turns off, the NO contact goes on again. When a preset time has elapsed after the start input turned off, the NO contact goes off.

NO contact goes on.														
Item	Terminal Nur	nber		Operation										
Power	(A) 2 - 10 (B) A - B													
Start	(A) 5 - 6 (B) 2 - 5					П								
Delayed	(A) 1 - 4, 8 - 11 (B) 1 - 7, 3 - 9	(NC)												
Contact	(A) 1 - 3, 9 - 11 (B) 4 - 7, 6 - 9	(NO)												
Indicator	PWR													
	OUT													
Set Time				<b>→</b> T	-	-	т		<del>∢ →</del> Ta	T	<b>←</b>		<del>←→</del> Ta	


#### F: One-Shot (signal start)

When the start input turns on while power is on, the NO output contact goes on. When a preset time has elapsed, the NO output contact goes off.

Item	Terminal Nur	nber	Operation									
Power	(A) 2 - 10 (B) A - B											
Start	(A) 5 - 6 (B) 2 - 5											
Delayed	(A) 1 - 4, 8 - 11 (B) 1 - 7, 3 - 9	(NC)										
Contact	(A) 1 - 3, 9 - 11 (B) 4 - 7, 6 - 9	(NO)										
Indicator	PWR											
indicator	OUT											
Set Time												




# Mounting B




#### Instructions

**Temperature Derating Curves** 

## Installation of Hold-Down Springs DIN Rail Mount Socket





#### **Switch Settings**



- ①Operator Mode Selector②Scale Selector③Time Range Selector
- Turn the selectors securely using a flat screwdriver 4mm wide (maximum).
   Note that incorrect setting may cause malfunction. Do not turn the selectors beyond their limits.
- Since changing the setting during timer operation may cause malfunction, turn power off before changing.

#### **Safety Precautions**

Special expertise is required to use Electronic Timers.

- All Electronic Timers are manufactured under IDEC's rigorous quality control system, but users must add a backup or fail safe provision to the control system when using the Electronic Timer in applications where heavy damage or personal injury may occur should the Electronic Timer fail.
- Install the Electronic Timer according to instructions described in this catalog.
- Make sure that the operating conditions are as described in the specifications. If you are uncertain about the specifications, contact IDEC in advance.
- In these directions, safety precautions are categorized in order of importance under Warning and Caution.

#### **Warnings**

Warning notices are used to emphasize that improper operation may cause severe personal injury or death.

- Turn power off to the Electronic timer before starting installation, removal, wiring, maintenance, and inspection on the Electronic Timer.
- · Failure to turn power off may cause electrical shocks or fire hazard.

 Do not use the Electronic Timer for an emergency stop circuit or interlocking circuit. If the Electronic Timer should fail, a machine malfunction, breakdown, or accident may occur.

#### **Caution**

Caution notices are used where inattention might cause personal injury or damage to equipment.

- The Electronic Timer is designed for installation in equipment. Do not install the Electronic Timer outside equipment.
- Install the Electronic Timer in environments described in the specifications. If
  the Electronic Timer is used in places where it will be subjected to high-temperature, high-humidity, condensation, corrosive gases, excessive vibrations,
  or excessive shocks, then electrical shocks, fire hazard, or malfunction could
  result.
- Use an IEC60127-approved fuse and circuit breaker on the power and output line outside the Electronic Timer.
- Do not disassemble, repair, or modify the Electronic Timer.
- When disposing of the Electronic Timer, do so as industrial waste.

#### **Accessories**

#### **DIN Rail Mounting Accessories**

#### **DIN Rail/Surface Mount Sockets and Hold-Down Springs**


DIN Rail/Surface Mount Sockets and Hold-Down Springs										
	DIN Rail Mount Socket			Applicable Hold-Down Spring						
Style	Appearance	Use with Timers	Part Number	Appearance	Part Number					
11-Pin Screw Terminal (dual tier)		RTE-P2	SR3P-05		SEV 303					
11-Pin FingerSafe Socket		RTE-P2	SR3P-05C		SFA-203					
8-Pin Screw Terminal	SEE TO SEE	275.04	SR2P-06							
8-Pin Fingersafe Socket	(C) (A) (A) (A) (A) (A) (A) (A) (A) (A) (A	RTE-P1	SR2P-05C	Car a Cara	SFA-202					
11-Blade Screw Terminal		RTE-B1 RTE-B2	SR3B-05							
DIN Mounting Rail Length 1000mm		_	BNDN1000							

#### **Panel Mounting Accessories**

#### Flush Panel Mount Adapter and Sockets that use an Adapter

Accessory	Description	Appearance	Use with	Part No.
Panel Mount Adapter	Adaptor for flush panel mounting RTE timers		All RTE timers	RTB-G01
	8-pin screw terminal		RTE-P1	SR6P-M08G
	11-pin screw terminal	(Shown: SR6P-M08G Wiring Socket Adapter)	RTE-P2	SR6P-M11G
Sockets for use with Panel Mount Adapter	8-pin solder terminal		RTE-P1	SR6P-S08
	11-pin solder terminal		RTE-P2	SR6P-S11

# 




RTE-P1 (8 pin) Terminal Style


**Dimensions** 




RTE-P2 (11 pin)Terminal Style



Panel Mount Adapter RTE Timer, 8-Pin and 11-Pin with SR6P-S08 or SR6P-S11



RTE Timer, 8-Pin with SR6P-M08G



RTE Timer, 11-Pin with SR6P-M11G

