Timers **IDEC**

GT3F Series — True OFF Delay Timers



- Key features of the GT3F series include:
- Mountable in sockets or flush panel
- "True" power OFF-delay up to 10 minutes
- No external control switch necessary
- Available with reset inputs





	GT3F-1	GT3F-2				
Operation	True power OFF-delay	1				
Time Range	0.05 seconds to 600 seconds					
Rated Voltage	100 to 240V AC, 50/60Hz 24V AC/DC					
Contact Rating	250V AC/30V DC, 5A (resistive load) 250V AC/30V D (resistive load)					
Contact Form	SPDT	DPDT				
Minimum Power Application Time	1 second					
Voltage Tolerance	AF20: 100 to 240V AC AD24: 21.6 to 26.4VDC, 20.4 to 26.4VAC					
Repeat Error	±0.2%, ±10 msec					
Voltage Error	±0.2%, ±10 msec					
Temperature Error	±0.2%, ±10 msec					
Setting Error	±10% maximum					
Insulation Resistance	100MΩ minimum					
Dielectric Strength	Between power and output terminals: 2,000V AC, 1 minute (SPDT) 1,500V AC, 1 minute (DPDT) Between contacts on different poles: 1,000V AC, 1 minute (DPDT) Between contacts of the same pole: 750V AC, 1 minute					
Power Consumption	AF20: 3.7VA (200V AC, 60Hz) AD24: 0.8W (DC), 1.2VA (AC)					
Mechanical Life	20,000,000 operations minimum					
Electrical Life	100,000 operations minimum					
Vibration Resistance	100m/sec ² (approximate 10G)					
Shock Resistance	Operating extremes: 100 m/sec ² (approximate 10G) Damage limits: 500 m/sec ² (approximate 50G)					
Operating Temperature	-10 to +50°C					
Storage Temperature	-30 to +80°C					
Operating Humidity	45 to 85% RH					
Weight (approximate)	77g	79g				

GT3F Table of Contents Specifications — G-36 Part Number List — G-37 Timing Diagrams/Schematics — G-37 Instructions: Setting Timer — G-39 Instructions: Wiring Inputs — G-40 GT3 Accessories — G-48 GT3 Instructions — G-50 GT3 Dimensions — G-52 Timing Diagrams Overview — G-4

للله

1. An inrush current flows during the minimum power application time. AF20: approximate 0.3A, AD24: approximate 0.6A

2. GT3F does not read the preset time range shown on the knob after power is turned off. Note that minimizing the preset time, by turning the knob to zero, does not shorten the delay time after power is removed.

Part Numbering List

Part Numbers: GT3F

Mode of Operation	Rated Voltage Code	Time Range	Output	Contact	Optional Input	Complete Part Number	
						8-Pin	11-Pin
Power OFF-delay		0.05	250V AC, 5A,	Delayed Reset GT3F-1AF20 GT3F-1AD24	Posot	GT3F-1AF20	GT3F-1EAF20
	AF20: 100 to 240VAC (50/60Hz)	seconds	(resistive load)		GT3F-1AD24	GT3F-1EAD24	
	AD24: 24V AC/DC	600	250V AC, 3A,	Delayed DPDT	None (8p) Reset (11p)	GT3F-2AF20	GT3F-2EAF20
		seconds to 600 seconds	(resistive load)			GT3F-2AD24	GT3F-2EAD24

1. Optional reset input resets the contact to the OFF state before time out.

Timing Diagrams/Schematics



2. For time ranges, see page G-39.

3. For sockets and accessory part numbers, see page G-48.

4. When power is applied, the NO output contact closes. When power is removed, the timing period begins. When time has elapsed, the NO contact opens.

5. For the timing diagram overview, see page G-4.

Timers **IDEC**



When power is applied, the NO contact closes. When power is removed, the timing period begins. When time has elapsed, the NO contact opens. Optional reset input will return contacts to original state before time elapses.

Instructions: Setting GT3F Timers



POWER Indicator ③ Setting

① Dial Selector 0-1, 0-3, 0-6, 0-18, 0-60

Steps	Desired Operation	S	election	Remarks		
	Base Time Ranges	1 Dial Selector	② Time Range Selector	_		
	0.05s to 1s	0 to 1				
	0.05s to 3s	0 to 3	1S	Time range can be selected from 1S and 10S using a flat screwdriver and five different dials of 0 to 1, 0 to 3, 0 to 6, 0 to 18, and 0 to 60 are displayed in		
1. Select a time range that	0.05s to 6s	0 to 6				
of time.	0.1s to 10s	0 to 1		the six windows by turning the Dial Selector, allowing for selecting the heat switch does not turn infinitely.		
	0.3s to 30	0 to 3				
	0.6s to 60	0 to 6	10S			
	1.8s to 180s	0 to 18				
	6s to 600s	0 to 60			I	
				Setting Examples:	lei	
2. The set time is selected by turning the \Im Setting Knob.			ıb.	1) When the Setting Knob ③ is set at 2.5, with Dial Selector ① 0 to 3 and Time Range Selector ② 1S selected, then the set time is 2.5 seconds.	rs	
				2) When the Setting Knob ③ is set at 5.0, with Dial Selector ① 0 to 60 and Time Range Selector ② 10S selected, then the set time is 500 seconds.		

Accessories: GT3 Series

DIN Rail Mounting Accessories

Part Numbers: DIN Rail/Surface Mount Sockets and Hold-Down Springs

	Applicable Hold-Down Springs				
Style	Appearance	Use with Timers	Part No.	Appearance	Part No.
8-Pin Screw Terminal (dual tier)		GT3A-1, 2, 3 (8-pin) GT3D-1, 2, 3 (8-pin) GT3F-1, 2 (8-pin) GT3W (8-pin) GT3S	SR2P-05		
11-Pin Screw Terminal (dual tier)		GT3A-1, 2, 3 (11-pin) GT3A-4, 5, 6 GT3D-1, 2, 3 (11-pin) GT3D-4, 8 GT3F-1, 2 (11-pin) GT3W (11-pin)	SR3P-05	<u></u>	SEA-203
8-Pin Fingersafe Socket		GT3A-1, 2, 3 (8-pin) GT3D-1, 2, 3 (8-pin) GT3F-1, 2 (8-pin) GT3W (8-pin) GT3S	SR2P-05C	19.95	0174 200
11-Pin Fingersafe Socket		GT3A-1, 2, 3 (11-pin) GT3A-4, 5, 6 GT3D-1, 2, 3 (11-pin) GT3D-4, 8 GT3F-1, 2 (11-pin) GT3W (11-pin)	SR3P-05C		
8-Pin Screw Terminal	AREA .	GT3A-1, 2, 3 (8-pin) GT3D-1, 2, 3 (8-pin) GT3F-1, 2 (8-pin) GT3W (8-pin) GT3S	SR2P-06	A 40 . 40	
11-Pin Screw Terminal		GT3A-1, 2, 3 (11-pin) GT3A-4, 5, 6 GT3D-1, 2, 3 (11-pin) GT3D-4, 8 GT3F-1, 2 (11-pin) GT3W (11-pin)	SR3P-06		SFA-202
DIN Mounting Rail Length 1000mm		_	BNDN1000		

Installation of Hold-Down Springs

DIN Rail Mount Socket





Hold-down Spring (sold separately)
SFA-203 (use two springs)

Panel Mount Socket





Panel Mounting Accessories

Part Numbers: Panel Mount Sockets and Hold-Down Springs

	Panel Mount S	Applicable HD Springs			
Style	Appearance	Use with Timers	Part No.	Appearance	Part No.
8-Pin Solder Terminal		GT3A- (8-pin) GT3D- (8-pin) GT3W- (8-pin) GT3F- (8-pin) GT3S	SR2P-51	8	
11-Pin Solder Terminal		GT3A- (11-pin) GT3D- (11-pin) GT3W- (11-pin) GT3F- (11-pin)	SR3P-51		SFA-402



1. For information on installing the hold-down springs, see page G-48.

Part Numbers: Flush Panel Mount Adapter and Sockets that use an Adapter

Accessory	Description	Appearance	Use with Timers	Part No.
Panel Mount Adapter	Adaptor for flush panel mounting GT3 timers		All GT3 timers	RTB-G01
Sockets for use with Panel Mount Adapter	8-pin screw terminal		All 8-pin timers	SR6P-M08G
	11-pin screw terminal	(Shown: SR6P-M08G for Wiring Socket Adapter)	All 11-pin timers	SR6P-M11G
	8-pin solder terminal		All 8-pin timers	SR6P-S08
	11-pin solder terminal		All 11-pin timers	SR6P-S11



2. No hold down springs are available for flush panel mounting.

Dimensions: GT3 Series



Analog GT3 Timer, 8-Pin with SR2P-06

Digital GT3 Timer, 8-Pin with SR2P-06



Analog GT3 Timer, 11-Pin with SR3P-06



When Mounting on DIN Rail BNDN: 3.59" (92mm) Maximum

> HD Spring SFA-202

> > 1

0.507"

(13mm

0.702

0.858" (22mm)

(18mm)

3.43" (88mm) Maximum

2.5

(64.2mm)

D∫INĿ_Rail

3

mm

0.039"

(1mm)

2.34" (60 mm

Digital GT3 Timer, 11-Pin with SR3P-06

.56"

0 0

1.404

(36mm)

(40mm



Analog GT3 Timer, 11-Pin with SR3P-05



Digital GT3 Timer, 11-Pin with SR3P-05

0.039"

(1mm)



G-52



Panel Mount Adapter

Analog GT3 Timer, 8-Pin and 11-Pin with SR6P-S08 or SR6P-S11



Digital GT3 Timer, 8-Pin and 11-Pin with SR6P-S08 or SR6P-S11



Mounting Hole Layout



Analog and Digital GT3 Timer, 8-Pin with SR6P-M08G



Analog and Digital GT3 Timer, 11-Pin with SR6P-M11G



General Instructions for All Timer Series

Load Current

With inductive, capacitive, and incandescent lamp loads, inrush current more than 10 times the rated current may cause welded contacts and other undesired effects. The inrush current and steady-state current must be taken into consideration when specifying a timer.

Contact Protection

Switching an inductive load generates a counter-electromotive force (back EMF) in the coil. The back EMF will cause arcing, which may shorten the contact life and cause imperfect contact. Application of a protection circuit is recommended to safeguard the contacts.

Temperature and Humidity

Use the timer within the operating temperature and operating humidity ranges and prevent freezing or condensation. After the timer has been stored below its operating temperature, leave the timer at room temperature for a sufficient period of time to allow it to return to operating temperatures before use.

Environment

Avoid contact between the timer and sulfurous or ammonia gases, organic solvents (alcohol, benzine, thinner, etc.), strong alkaline substances, or strong acids. Do not use the timer in an environment where such substances are prevalent. Do not allow water to run or splash on the timer.

Vibration and Shock

Excessive vibration or shocks can cause the output contacts to bounce, the timer should be used only within the operating extremes for vibration and shock resistance. In applications with significant vibration or shock, use of hold down springs or clips is recommended to secure a timer to its socket.

G

Timing Accuracy Formulas

Timing accuracies are calculated from the following formulas:

Repeat Error

= ± <u>1</u> x <u>Maximum Measured Value – Minimum Measured Value</u> x 100% 2 Maximum Scale Value

Voltage Error

= ± <u>Tv - Tr</u>x 100% Tr

 T_{v} : Average of measured values at voltage V $T_{r_{\rm c}}$ Average of measured values at the rated voltage

Temperature Error

= ± <u>Tt - T20 </u>x 100% T20

 T_t : Average of measured values at °C T_{20} : Average of measured values at 20°C

Setting Error

= ± <u>Average of Measured Values - Set Value</u> x 100% Maximum Scale Value The time range is calibrated at its maximum time scale; so it is desirable to use the timer at a setting as close to its maximum time scale as possible. For a more accurate time delay, adjust the control knob by measuring the operating time with a watch before application.

Input Contacts

Use mechanical contact switch or relay to supply power to the timer. When driving the timer with a solid-state output device (such as a two-wire proximity switch, photoelectric switch, or solid-state relay), malfunction may be caused by leakage current from the solid-state device. Since AC types comprise a capacitive load, the SSR dielectric strength should be two or more times the power voltage when switching the timer power using an SSR.

Generally, it is desirable to use mechanical contacts whenever possible to apply power to a timer or its signal inputs. When using solid state devices, be cautious of inrushes and back-EMF that may exceed the ratings on such devices. Some timers are specially designed so that signal inputs switch at a lower voltage than is used to power the timer (models designated as "B" type).